
STONEAGE INSTRUCTIONS

DESIGNED IN ICELAND



VOLTAGE UP

VOLTAGE DOWN

POWER

TO POWER ON THE MACHINE, PRESS AND HOLD THE BOTTOM BUTTON. A SINGLE CLICK INITIATES OR PAUSES THE OPERATION, WHILE A DOUBLE CLICK SEAMLESSLY SWITCHES BETWEEN MODES.





